

Quick guide

Carefully read the safety instructions in the operating manual before using the appliance for the first time!

Operating the appliance

- 1) Pull the baking tin **6** upwards and out of the appliance.
- 2) Push the kneading blades **7** onto the drive shafts in the baking tin **8**. Ensure that they are fixed firmly in place.
- 3) Place the ingredients for your recipe into the baking tin **8** in the specified sequence. As a rule, you should add the liquids first, followed by sugar, salt and flour and finally the yeast.
- 4) Replace the baking tin **8** in the breadmaker. Ensure that it clicks into place properly.
- 5) Close the lid **2**.
- 6) Insert the mains plug into the socket.
- 7) Switch the appliance on using the On/Off switch (0/I) **5**. You will hear a beep and the display **A** will show the programme number **e** and time **D** for the programme 1.

Starting a programme

- 1) Select the desired programme using the programme selector button **G**.
- 2) Select the required bread weight **a** with button **F**.
- 3) Select the desired browning level **d** using button **C**.
- 4) Set the timer using the arrow buttons **D** or start the programme immediately with the Start/Stop button **B**.


Pausing/stopping the programme

- To pause the programme, briefly press the Start/Stop button **B**, the time indicator **D** will flash on the display **A**. Press the Start/Stop button **B** again to resume the programme.
- If the programme ends automatically, you will hear several beeps and the time indicator **D** will display 0:00. The appliance will switch to warming mode for 60 minutes.
- To end the programme or warming mode prematurely, press and hold down the Start/Stop button **B** until you hear a long beep.

Switching the appliance off

- Once you have finished using the appliance, switch it off using the On/Off switch (0/I) **5** and pull the mains plug out of the mains socket.

Control panel/display



A Display

- a Weight selection (1000 g / 1250 g / 1500 g)
- b Remaining programme time in hours / programmed timer / programmed phase time (programme 16)
- c Remove function – while "RMV" (= "Remove") is displayed, the kneading blades **7** can be removed.
- d Selected browning level/quick mode (light , medium , dark , quick )
- e Active programme number
- f Active programme phase
- g Add function – while "ADD" is displayed, further ingredients can be added to the dough.

B Start/Stop button

Button for starting, stopping or pausing a programme.

C Select browning level/quick mode

Button for selecting the browning level or quick mode (light/medium/dark/quick). Press the button repeatedly until the arrow **d** appears above the desired browning level. Or activate quick mode to speed up the baking process.

D Setting the timer

Buttons for setting the timer for time-delayed baking.

E Operating light

The operating light **E** indicates whether a programme is currently active.

F Set bread weight

Button for selecting the bread weight (1000 g / 1250 g / 1500 g). Press the button repeatedly until the arrow **a** appears below the desired weight.

G Select programme

Button to select the desired programme (1 - 16). The display **A** shows the programme number **e** and time **b**.